



SUNOVA SOLAR

Leading one-stop PV Supplier

Sunova-eFox-WP Series

Off-Grid Energy Storage System



User Manual

Version: EN V2.0

Copyright

This user manual's copyright belongs to original manufacturer. Any unit or individual shall not reproduce or partially reproduce the contents of this manual without permission, and shall not convert or distribute in any form or means. Manufacturer reserves the copyright, and owns the power of interpretation. All information may be changed or updated without notice, please understand.

Preface

Sunova-eFox-WP Series Energy Storage System is a multi-functional power supply device designed to comprehensively use for residential and commercial projects. With built-in lithium battery, this system can provide uninterrupted and stable power supply, and ensure the normal use of the utility when the grid is out. This device can run in the most economical and practical mode based on the user requirement to bring objective economical benefits and not cause any environmental pollution.

This user manual mainly introduces the operation, installation and specification of the device. Please read through this user manual before install and operate the system. Please keep this user manual for future use.

Contents

| | |
|--------------------------------|----|
| 1. Introduction | 04 |
| 1.1 Application | 04 |
| 1.2 Components | 08 |
| 1.3 Sunova-eFox-WP Dimension | 09 |
| 1.4 Quality Inspection | 10 |
| 1.5 Label | 10 |
| 1.6 Safety | 10 |
| 2. Installation | 12 |
| 2.1 Device Overview | 12 |
| 2.1.1 Device Carrying | 12 |
| 2.1.2 Unboxing Guide | 13 |
| 2.1.3 Installation | 18 |
| 2.2 Electric Installation | 19 |
| 2.2.1 Making cables | 19 |
| 2.2.2 Battery Wiring Procedure | 19 |
| 3. Operation | 22 |
| 3.1 LCD Display | 22 |
| 3.2 LCD Display Icons | 23 |
| 3.3 LCD Setting | 26 |
| 3.4 Display Information | 35 |
| 3.5 Operating Mode | 39 |
| 3.6 Monitoring | 39 |
| 4. Maintenance | 40 |
| 4.1 Fault Code | 40 |
| 4.2 Warning Indicator | 41 |
| 4.3 Specification | 43 |
| 4.4 Trouble shooting | 44 |
| 4.5 Activation | 45 |

1 Introduction

1.1 Application

Sunova-eFox-WP series can connect with solar panels, grid (or generator), load, it built-in lithium battery, hybrid inverter and energy management system. Sunova-eFox-WP has four working modes: SOL (Solar first), UEI (Utility first), SBU(Solar-Battery-Utility), SUB (Solar-Utility -Battery). These working modes are described refer to the setting part.









Figure 1 Sunova-eFox-WP Working Diagram

1.1.1 Working Modes

| | |
|-------------------|---|
| Definition | <p>Battery voltage too low: Lower than the value of setting 12.</p> <p>Battery voltage too high: Higher than the value of setting 13.</p> <div style="text-align: center;"> <p>Battery -----></p> <p>PV Panel =====></p> <p>Utility Grid - . - . - .></p> </div> |
|-------------------|---|

| | |
|--|--|
| <p>SOL (Solar first): Solar energy provides power to the loads as first priority.</p> | <p>When PV power is greater than the consumption, and the battery capacity is low, the PV will supply power to the load and charge the battery at the same time.</p>  |
| | <p>When PV power is less than the consumption, and the battery capacity is high, PV and battery supply power to the load at the same time.</p>  |
| <p>UEI (Utility first): Utility grid will provide power to the loads as first priority.</p> | <p>The grid supplies power to the load and charges the battery when the battery capacity is low.</p>  |
























1.2 Components

After unpacking the package, please inspect the components based on the below table.

Table 1 Component list

| NO. | Pictures | Description | Quantity |
|-----|---|--|----------|
| 1 |  | Sunova-eFox-WP Residential energy storage system | 1 pcs |
| 2 |  | Base | 1pcs |
| 3 |  | Waterproof aviation male pin plug | 1pcs |
| 4 |  | Waterproof aviation female pin plug | 1pcs |
| 5 |  | D4B Connector(Male) | 1pcs |
| 6 |  | D4B Connector(female) | 1pcs |
| 7 |  | Tube terminal red;E6012 | 2 pcs |
| 8 |  | Tube terminal black;E6012 | 2pcs |
| 9 |  | Tube terminal yellow;E6012 | 2pcs |
| 10 |  | Communication connector | 2 pcs |

| NO. | Pictures | Description | Quantity |
|-----|---|---|----------|
| 11 |  | Bracket | 2pcs |
| 12 |  | Sunk screw, M4-8 | 6pcs |
| 13 |  | Phillips external hexagon combination screws, M6-14 | 4pcs |
| 14 |  | Hexagonal wrench, D-3mm: L type | 1pcs |
| 15 |  | Expansion screw | 4 pcs |
| 16 |  | User manual | 1 pcs |
| 17 |  | APP Operation Guide | 1 pcs |
| 18 |  | Qualified Certificate | 1 pcs |
| 19 |  | Packing List | 1 pcs |

1.3 Sunova-eFox-WP Dimension

The size is slightly different according to the type, below for reference.




Figure 2 Sunova-eFox-WP Dimension




1.4 Quality Inspection

Before installation, please confirm that the packaging is unbroken, and after unpacking, check that all parts are consistent with the packaging list and are in good condition.

Table 2 Quality Inspection





| Operation | Warning |
|--------------------------|-------------------|
| Check Package | No damage |
| Check Component | No loss or damage |
| Check built-in Accessory | No loss or damage |

1.5 Label

| | |
|---|---|
|  | <ul style="list-style-type: none"> • Danger: Possibility of fatal voltage |
|  | <ul style="list-style-type: none"> • Warning: Possibility of device damage or personal injury |
|  | <ul style="list-style-type: none"> • Warning: Heat injure |


1.6 Safety

This user manual includes safety introduction. Please read this manual carefully before installing, maintaining and operating the equipment. If you do not operate in accordance with this manual, if there is equipment damage or personal injury or death, manufacturer will not be responsible for it.

| | |
|---|---|
|  | <ul style="list-style-type: none"> ❖ Must be grounded before operation. |
|  | <ul style="list-style-type: none"> ❖ Do not open the cover of the storage unauthorized. The electrical parts and components inside of the storage are electrostatic. Take measurements to avoid electrostatic discharge during relevant operation. |
|  | <ul style="list-style-type: none"> ❖ Only qualified electricians are allowed to operate the storage under the permission of local power departments. Ensure reliable installation and electrical connection before operation. ❖ Only qualified electricians are allowed to perform the maintenance, inspection, and components replacement of this product. |
|  | <ul style="list-style-type: none"> ❖ Do not remove any part and component of the storage unintended. Otherwise, damage to the device and physical injury may occur. |

2 Installation


2.1 Device Overview



- | | | |
|------------------------------|-------------------|-------------------------------|
| ① AC Input | ② AC Output | ③ PV Input |
| ④ Inverter Switch | ⑤ WiFi Antenna | ⑥ Inverter communication port |
| ⑦ Battery communication port | ⑧ Battery Breaker | |
| ⑨ LCD Screen | ⑩ Bracket | |

Figure 3 Device Overview

2.1.1 Device Carrying

| | |
|---|--|
|  | <p>Warning! The device is very heavy, which may cause personal injury.</p> <ul style="list-style-type: none"> • Please note that the device weight when move or deliver the device. • Select the firm installation platform. • Use proper tools for installation. • At least two people to install. |
|---|--|

2.1.2 Unboxing Guide

The iron buckle is sharp, please pay attention to personal safety when unboxing!

(1) Place the wooden box on a flat ground.




Figure 4

(2) Pry open the buckle of the wooden box, remove the top plate of the wooden box, and take out the accessory box and the base.




Figure 5

(3) Remove the side boards one by one.






Figure 6


(4) Move the bottom of device out of the bottom of the wooden box by 10-15mm.




(5) Install the base. Take out the screws from the accessory box, and tighten them with a Phillips screwdriver. Note that the arc of the bottom plate faces the direction of the screen.





(6) Tighten the screws with a wrench.








(7) One person pushes up from point "A", and two persons push up from point "B".



(8) Take out the machine, the machine is heavy, please pay attention.

| | |
|---|--|
|  | <p>Warning:</p> <ul style="list-style-type: none"> ❖ Ensure the installed place be well ventilate and conform to device using condition. ❖ No flammable and combustible objects are allowed to put within 4m. ❖ The environmental temperature shall keep between 0°C and 40°C. |
|  | <p>Warning:</p> <ul style="list-style-type: none"> ❖ No smoking and setting off fireworks nearby. ❖ Ensure clean and ventilate in the surrounding area. ❖ Ensure the wiring conform to requirement to avoid fire. |

| | |
|---|--|
|  | <p>❖ Adequate ventilation of the room or location in which the device containing vented or valve-regulated batteries is located, to prevent the accumulation of hazardous gases.</p> |
|  | <p>-Servicing of batteries should be performed or supervised by personnel knowledgeable about batteries and the required precautions.</p> <p>-When replacing batteries, replace with the same type and number of batteries or battery packs.</p> <p>-CAUTION: Do not dispose of batteries in a fire. The batteries may explode.</p> <p>-CAUTION: Do not open or damage batteries. Released electrolyte is harmful to the skin and eyes. It may be toxic.</p> <p>-CAUTION: A battery can present a risk of electrical shock and high short-circuit current. The following precautions should be observed when working on batteries:</p> <ol style="list-style-type: none"> a) Remove watches, rings, or other metal objects. b) Use tools with insulated handles. c) Wear rubber gloves and boots. d) Do not lay tools or metal parts on top of batteries. e) Disconnect charging source prior to connecting or disconnecting battery terminals. f) Determine if battery is inadvertently grounded. If inadvertently grounded, remove source from ground. g) rinse acid splashes thoroughly with clear water for a long time and consider consulting a doctor. <p>Contact with any part of a grounded battery can result in electrical shock. The likelihood of such shock can be reduced if such grounds are removed during installation and maintenance (applicable to equipment and remote battery supplies not having a grounded supply circuit).</p> <p>-Battery terminals and connectors shall be accessible for maintenance with the correct tools.</p> |

| | |
|---|---|
|  | <ul style="list-style-type: none"> ❖ All electrical connections must be in accordance with local and national standards. ❖ Only with the permission of the utility grid, the storage can be connected to the utility grid. Disconnect the storage from all the external power sources before service! Do not open the enclosure when the storage is working. ❖ When the enclosure lid is removed, live components can be touched which can result in death or serious injury due to electric shock. Batteries deliver electric power, resulting in burns or a fire hazard when they are short-circuited, or wrongly installed. |
|  | <ul style="list-style-type: none"> ❖ All the AC cables should be equipped with correctly colored cables for distinguishing. Please refer to related standards about the wiring color. |
|  | <ul style="list-style-type: none"> ❖ Do not touch live parts until 5 minutes after disconnection from the power sources. |

2.1.3 Installation

(1) Indoor installation, vertical placement. The installation site should be able to ensure the stability and safety of the device. The distance around the device should be more than 200mm to ensure good ventilation.

(2) Install the device against the wall and fix the device to the wall with expansion screws.

(3) The distance from the device to the wall can be adjusted through the device suspension loop.




Figure 7 Install suspension loop




Figure 8 Install against the wall

2.2 Electric Installation

The Sunova-eFox-WP is ground mounted, shall put on the ground vertically.

2.2.1 Making cables

PV cable assembling:

- (1) Stripping the red and black 6AWG PV cables, insert them into the jacks and pins of the PV connector in the accessories, and press them with crimping pliers.
- (2) Insert the crimped cable into the plastic shell of PV connector.
- (3) Tighten the plastic nut of PV connector to fix the cable.




Figure 9

2.2.2 Battery Wiring Procedure

- (1) Cut off the circuit breaker of grid and PV .
- (2) Ensure Smart Unit be not carelessly turned on.
- (3) Wiring refer to the Figure.
- (4) Install the cover.




Figure 10

Table 3 Cable Size

| Function | Typical Power | Cable size | Torque | |
|----------|----------------|------------|--------|-----------|
| Load | Sunova-eFox-WP | 3kVA/5kVA | 10AWG | 1.4~1.6Nm |
| Grid | | 3kVA/5kVA | 10AWG | 1.4~1.6Nm |
| PV | | 3kVA/5kVA | 10AWG | 1.4~1.6Nm |

3 Operation

3.1 LCD Display

The operation and display panel, shown in below chart, is on the front panel of Sunova-eFox-WP. It includes three indicators, four function buttons and a LCD display, indicating the operating status and input/output power information.




Figure 14 LED Display

Table 4 LED Indicator

| LED Indicator | | Messages |
|---------------|-------|--|
| | Green | Solid On Output is powered by utility. |
| | | Flashing Output powered by battery or PV in battery mode. |
| | Green | Solid On Battery is fully charged. |
| | | Flashing Battery is charging. |
| | Red | Solid On Fault occurs in the inverter. |
| | | Flashing Warning condition occurs in the inverter. |

Table 5 Function Button

| Function Button | Description |
|-----------------|--|
| ESC | To exit setting mode |
| UP | To go to previous selection |
| DOWN | To go to next selection |
| ENTER | To confirm the selection in setting mode or enter setting mode |

3.2 LCD Display Icons


















Figure 15 Display Icons

Table 6 Icon Information

| Icon | Description |
|---|---|
| AC Input Information | |
|  | AC input icon |
| <div style="display: flex; align-items: center;"> 8.8.8 <div style="display: flex; flex-direction: column; align-items: center;"> KW V Hz A </div> </div> | Indicates AC input power, AC input voltage, AC input frequency, AC input current. |
| AC BYPASS | Indicates AC power loads by bypass. |

| Icon | Description |
|---|--|
| PV Input Information | |
|  | PV input icon |
|  | Indicate PV input power, voltage, current, etc. |
| Output Information | |
|  | Inverter Icon |
|  | Indicate output voltage, current, frequency, Inverter temperature. |
| Load Information | |
|  | Load Icon |
|  | Indicates power of load, power percentage of load. |
|  | Indicates overload happened. |
|  | Indicates short circuit happened. |
| Battery Information | |
|  | Battery Icon |
|  | Indicates battery voltage, energy percentage, battery current. |
|  | Indicates SLA battery |
|  | Indicates Lithium battery |
|  | Indicates charging source priority: Solar first, Utility first, solar and utility, or only solar |









| Icon | Description |
|---|---|
| Other Information | |
| SOL.FIRST BAT.FIRST UTI.FIRST | Indicates output source priority: Solar first, Utility first, SBU mode or SUB mode. |
|  | Indicates warning code or fault code. |
|  | Indicates a warning or a fault is happening. |
|  | Indicates it is during setting values. |
|  | Indicates the alarm is disabled. |

Table 7 Battery information

| In AC mode, battery icon will present battery capacity | | |
|--|---|--|
| Battery Status |  | SOC < 25% |
| |  | $25\% \leq \text{SOC} < 50\%$ |
| |  | $50\% \leq \text{SOC} < 75\%$ |
| |  | $75\% \leq \text{SOC}$ |
| In AC mode, battery icon will present battery charging status. | | |
| Status | Battery SOC | LCD Display |
| Constant current mode/Constant voltage mode | SOC < 25% | 4 bars will flash in turns. |
| | $25\% \leq \text{SOC} < 50\%$ | Bottom bar will be on and the other three bars will flash in turns. |
| | $50\% \leq \text{SOC} < 75\%$ | Bottom two bars will be on and the other two bars will flash in turns. |
| | $75\% \leq \text{SOC}$ | Bottom three bars will be on and the top bar will flash in turns. |

3.3 LCD Setting

After pressing and holding ENTER button for 3 seconds, unit enter setting mode. Press “UP” or “DOWN” button to select setting programs. Then, press “ENTER” button to confirm the selection or ESC button to exit.







Table 8 Setting Program

| Program | Description | Setting option | |
|---|---|--|---|
| 01 | Output source priority selection: To configure load power source priority | Solar First |  |
| | | <p>Solar energy provides power to the loads as first priority.</p> <p>If solar energy is not sufficient to power all connected loads, battery energy will supply power to the loads at the same time.</p> <p>Utility grid provides power to the loads only when any below one condition happens:</p> <ul style="list-style-type: none"> -Solar energy is not available -Battery voltage drops to low-level warning voltage or the setting point in program 12. | |
| | | Utility First |  |
| | | <p>Utility grid will provide power to the loads as first priority.</p> <p>Solar and battery energy will provide power to the loads only when utility power is not available.</p> | |
| SBU Priority (Default) |  | | |
| <p>Solar energy provides power to the loads as first priority.</p> <p>If solar energy is not sufficient to power all connected loads, battery energy will supply power to the loads at the same time.</p> <p>Utility grid provides power to the loads only when battery voltage drops to either low-level warning voltage or the setting point in program 12.</p> | | | |

| Program | Description | Setting option | |
|---------|---|--|---------------------------|
| | | SUB Priority | OPPF SUB 001 ^o |
| | | <p>Solar energy provides power to the loads as first priority.</p> <p>If solar energy is not sufficient to power all connected loads, solar and utility grid will supply power to the loads at the same time.</p> <p>Battery provides power to the loads only when solar energy is not sufficient and there is no utility.</p> | |
| 03 | AC input voltage range | Appliances (default) | ACU APL 003 ^o |
| | | <p>If selected, acceptable AC input voltage range will be within 90~280Vac.</p> | |
| | | UPS | ACU UPS 003 ^o |
| | | <p>If selected, acceptable AC input voltage range will be within 170~280Vac.</p> | |
| | | Generator | ACU GEN 003 ^o |
| | | <p>If selected, acceptable AC input voltage range will be within 90~280Vac. In this mode, the max charging current is 30A.</p> | |
| 04 | Power saving mode enable/disable | Disable (default) | SAVE DIS 004 ^o |
| | | <p>If disabled, no matter connected load is low or high, the on/off status of inverter output will not be effected.</p> | |
| | | Enable | SAVE ENA 004 ^o |
| | | <p>If enabled, the inverter output will be off when connected load is pretty low or not detected.</p> | |





| Program | Description | Setting option | |
|---------|------------------------------|--|---------------------------|
| 05 | Battery type | AGM | BATT AG1 005 ^o |
| | | Flooded | BATT FLD 005 ^o |
| | | Lithium (Default) | BATT LI 005 ^o |
| | | Only suitable when communicated with BMS | |
| | | User-defined | BATT USE 005 ^o |
| | | If "User-Defined" is selected, battery charge voltage and low DC cut-off voltage can be set up in program 19, 20 and 21. | |
| | | User-defined 2 | BATT USE 005 ^o |
| | | Suitable when lithium battery without BMS communication If "User-defined 2" is selected, battery charge voltage and low DC cut-off voltage can be set up in program 19, 20 and 21. It is recommended to set to the same voltage in program 19 and 20 (full charging voltage point of lithium battery). The inverter will stop charging when the battery voltage reaches this setting. | |
| 36 | RS485 communication protocol | Protocol 1 | PtCL L01 036 ^o |
| | | Protocol 2 | PtCL L02 036 ^o |
| | | : | : |
| | | Protocol 50 | PtCL L50 036 ^o |
| | CAN communication protocol | Protocol 51 | PtCL L51 036 ^o |
| | | Protocol 52 | PtCL L52 036 ^o |
| | | : | : |
| | | Protocol 99 | PtCL L99 036 ^o |

| Program | Description | Setting option | |
|---|--|--|-----------------------------------|
| <p>NOTE 1: When set the battery type as “LI” in program 05, the setting option 12,13,21 will change to display percent. At the “LI” type battery, the maximum charge current can’t be modify by the user. When the communication fail, the inverter will cut off output. If it lost the communication with the battery, you can set the battery type to “USER” for emergency, then contact the installer.</p> | | | |
| 12 | Setting SOC point back to utility source when selecting “SBU priority” or “Solar first” in program 01. | b2AC 50 012° | Default 30%, 20%~50% Settable |
| 13 | Setting SOC point back to battery mode when selecting “SBU priority” or “Solar first” in program 01. | AC2b 95 013° | Default 65%, 30%~100% Settable |
| 21 | Low DC cut-off SOC, If “LI” is selected in program 05,this program can be set. | CUEU 20 021° | Default 10%, 5%~30% Settable |
| <p>NOTE 2: When the inverter is cut-off, it must to charge by solar or utility until the SOC> setting 21+10%, the inverter will restart.</p> | | | |
| 06 | Auto restart when overload occurs | Restart Disable (Default) LdFS d15 006° | Restart Enable LdFS ENR 006° |
| 07 | Auto restart when over temperature occurs | Restart Disable (Default) LdFS d15 007° | Restart Enable LdFS ENR 007° |

| Program | Description | Setting option | |
|--|---|---|--|
| 08 | Output voltage | 230V(Default) OUUV 230 008 ^o | 220V OUUV 220 008 ^o |
| | | 240V OUUV 240 008 ^o | 208V OUUV 208 008 ^o |
| | | *This setting is only available when the inverter is in standby mode (Switch off). | |
| 09 | Output frequency | 60Hz OUUF 60 009 ^o | 50Hz(Default) OUUF 50 009 ^o |
| | | *This setting is only available when the inverter is in standby mode (Switch off). | |
| 11 | Maximum utility charging current. | ACI 30 ^A 011 ^o 3.5K :Default 30A, 0A~60A Settable 5K :Default 30A, 0A~80A Settable | |
| 14 | Charger source priority: To configure charger source priority | If this off grid solar inverter is working in Line, Standby or Fault mode, Charger source can be programmed as below: | |
| | | Solar First <small>SOL</small> CGPF 050 014 ^o | Solar energy will charge battery as first priority. Utility will charge battery only when solar energy is not available. |
| | | Solar and Utility grid <small>SOL-UTL</small> (Default) CGPF 5NU 014 ^o | Solar energy and utility grid will both charge battery. |
| Only solar <small>Only SOL</small> CGPF 050 014 ^o | Solar energy will be the only charger source no matter utility is available or not. | | |

| Program | Description | Setting option | |
|---------|---|--|---|
| | | If this off grid solar inverter is working in Battery mode or Power saving mode, only solar energy can charge battery. Solar energy will charge battery if it' s available and sufficient. | |
| 15 | Alarm Control | Alarm on (default) BUZZ ON 015° | Alarm off BUZZ OFF 015° |
| 16 | Backlight control | Backlight on(default) LEdb ON 016° | Backlight off LEdb OFF 016° |
| 17 | Beeps while primary source is interrupted | Alarm on (default) ALAR ON 017° | Alarm off ALAR OFF 017° |
| 18 | Overload bypass | Bypass Disable BYP DIS 018° | Bypass enable (Default) BYP ENA 018° |
| | | When enabled, the unit will transfer to line mode if overload occurs in battery mode. | |
| 28 | Address setting (for expansion) | No need to set, keep it default | |
| 37 | Real time setting---Year | 2018 | 037° Default 2018, Range 2018-2099 |
| 38 | Real time setting---Month | 12 | 038° Default 01, Range 01-12 |
| 39 | Real time setting---Date | 13 | 039° Default 01, Range 01-31 |
| 40 | Real time setting---Hour | 13 | 040° Default 00, Range 00-23 |
| 41 | Real time setting---Minute | 50 | 041° Default 00, Range 00-59 |
| 42 | Real time setting---Second | 50 | 042° Default 00, Range 00-59 |

| Program | Description | Setting option | |
|---------|------------------------------------|--|--|
| 43 | Battery equalization | Battery equalization enable EQ ENR 043 | Battery equalization disable (default) EQ d15 043 |
| | | If "flooded" or "user-Defined" is selected in program 05, this program cannot be set up. | |
| 44 | Battery equalization voltage | EQV 58.4 044 | Default 58.4V, 48.0V-58.4V Settable |
| 45 | Battery equalized time | EQT | Default 60Min, 5min-90min Settable |
| | | EQT 60 045 | |
| 46 | Battery equalized timeout | EQT | Default 120Min, 5min-90min Settable |
| | | EQT0 120 046 | |
| 47 | Equalization interval | EQI | Default 30 days, 5days-90days Settable |
| | | EQI 30 047 | |
| 48 | Equalization activated immediately | Equalization activated immediately ON EQ ON 048 | Equalization activated immediately OFF (default) EQ OFF 048 |
| | | If equalization function is enabled in program 43, this program can be setup. If " ON" is selected in this program, it's to activate battery equalization immediately and LCD main page will shows "EQ". If" OFF "is selected, it will cancel equalization function until next activated equalization time arrives based on program 47 setting. At this time, "EQ"will not be show in LCD main page. | |

| Program | Description | Setting option | |
|-------------------------------------|----------------------------|---|--|
| 49 | Utility grid charging time | 0000 (Default)   | The time allows utility grid to charge the battery. Use 4 digits to represent the time period, the upper two digits represent the time when utility grid start to charge the battery, setting range is from 00 to 23, and the lower end to charge the battery, setting range is from 00 to 23. (e.g. 2320 represents the time allows utility grid end to charge the battery is from 23:00 to the next day 20:59, and the utility grid charging is prohibited outside for this period). |
| 50 | AC output time | 0000 (Default) Allow inverter to power the load all day run.   | The time allows inverter to power the load. Use 4 digits to represent the time period, the upper two digits represent the time when inverter start to power the load, setting range is from 00 to 23, and the lower two digits represent the time when inverter end to power the load, setting range is from 00 to 23. (e.g. 2320 represents the time allows inverter to power the load is from 23:00 to the next day 20:59, and the inverter AC output power is prohibited outside of this period). |
| 02/19/20/22/23/24/43/44/45/46/47/48 | | No need to set, keep it default | |

3.4 Display Information

The LCD display information will be switched in turns by pressing "UP" or "DOWN" key. The selection information is switched as below order: voltage, frequency, current, power, firmware version.




Figure 16 Display Information









Table 9 Display Information







| Setting Information | LCD display |
|--|---|
| ① AC input voltage ② Output Voltage ③ Load Percentage ④ PV input voltage ⑤ Battery voltage ⑥ Warning or Fault code (Default display on screen) |  |
| ① AC input Frequency ② Output Frequency ③ Load power in VA ④ PV energy sum in KWH ⑤ Battery percentage ⑥ Warning or Fault code |  |
| ① AC input current ② Output Current ③ Load Percentage ④ PV input current ⑤ Battery charging current ⑥ Warning or Fault code |  |
| ① AC input power in watts ② Inverter temperature ③ Load power in watts ④ PV energy sum in KWH ⑤ Battery percentage ⑥ Warning or Fault code |  |
| Firmware Version CUP1:040-00-b21; CUP2: 041-00-b21 |  |



| Setting Information | LCD display |
|---|-------------|
| Time (15:20:10, December 15, 2018) | |

3.5 Operating Mode

Table 10 Operating mode description

| Operation mode | Description | LCD display | |
|--|--|-------------------------------------|-------------------------|
| Standby Mode / Power Saving Mode Note: *Standby mode: The inverter is not turned on yet but at this time, the inverter can charge battery without AC output. *Power saving mode: If enabled, the output of inverter will be off when connected load. | No output is supplied by the unit but it still can charge batteries. | Charge by utility and PV energy | Charging by utility |
| | | Charging by PV energy | No charging |

| Operation mode | Description | LCD display | |
|--|--|--|---|
| <p>Fault Mode Note: * Fault mode: Errors are caused by inside circuit or external reasons such as over temperature, output short circuit and so on.</p> | <p>PV energy and utility can charge batteries</p> | <p>Charge by utility and PV energy</p>  | <p>Charging by utility grid</p>  |
| <p>Utility grid Mode</p> | <p>The unit will provide output power from the mains. It can also charge the battery at line mode.</p> | <p>Charging by PV energy</p>  | <p>No charging</p>  |
| <p>Utility grid Mode</p> | <p>The unit will provide output power from the mains. It can also charge the battery at line mode.</p> | <p>Charging by utility grid</p>  | <p>No battery connected</p>  |




















| Operation mode | Description | LCD display |
|----------------------------|---|---|
| <p>Battery Mode</p> | <p>The unit will provide output power from battery and PV power</p> | <p>Power from battery and PV power</p>  <p>The diagram illustrates power flow in Battery Mode. On the left, a sun icon represents PV power, which flows into a central inverter unit. Below the inverter is a battery icon labeled 'SOL'. A dashed arrow points from the battery to the inverter, and another dashed arrow points from the inverter to a house icon on the right, representing power output to the load.</p> |
| | | <p>Battery from battery power only</p>  <p>The diagram illustrates power flow when only battery power is used. A battery icon labeled 'SOL' is shown below the inverter unit. A dashed arrow points from the battery to the inverter, and another dashed arrow points from the inverter to a house icon on the right, representing power output to the load.</p> |

3.6 Monitoring

For data monitoring, please refer to the "APP Operation Guide" manual.

4 Maintenance

4.1 Fault Code

| Fault Code | Fault Event | Icon on |
|------------|------------------------------|---|
| 01 | Fan is locked |  |
| 02 | Over temperature |  |
| 03 | Battery voltage is too high |  |
| 04 | Battery voltage is too low |  |
| 05 | Output short circuited |  |
| 06 | Output voltage is too high |  |
| 07 | Overload time out |  |
| 08 | Bus voltage is too high |  |
| 09 | Bus soft start failed |  |
| 11 | Main relay failed |  |
| 51 | Over current or surge |  |
| 52 | Bus voltage is too low |  |
| 53 | Inverter soft start failed |  |
| 55 | Over DC voltage in AC output |  |
| 56 | Battery connection is open |  |
| 57 | Current sensor failed |  |
| 58 | Output voltage is too low |  |
| 80 | CAN fault |  |
| 81 | Host loss |  |

4.2 Warning Indicator

| Warning Code | Warning Event | Audible Alarm | Icon flashing |
|--------------|---|----------------------------|-----------------|
| 01 | Fan locked when inverter is on | Beep 3 times every second | 01 [△] |
| 02 | Over temperature | Beep once every second | 02 [△] |
| 03 | Battery over charged | Beep once every second | 03 [△] |
| 04 | Low battery | Beep once every second | 04 [△] |
| 07 | Overload | Beep once every 0.5 second | 07 [△] |
| 10 | Output power derating | Beep once every 3 second | 10 [△] |
| 12 | Solar charger stop due to low battery | Beep once every second | 12 [△] |
| 13 | Solar charger stop due to high PV voltage | Beep once every second | 13 [△] |
| 14 | Solar charger stop due to overload | Beep once every second | 14 [△] |
| 15 | Parallel input utility grid different | Beep once every second | 15 [△] |
| 16 | Parallel input phase error | Beep once every second | 16 [△] |
| 17 | Parallel output phase loss | Beep once every second | 17 [△] |
| 18 | Buck over current | Beep once every second | 18 [△] |
| 19 | Battery disconnect | No beep | 19 [△] |
| 20 | BMS communication error | Beep once every second | 20 [△] |
| 21 | PV power insufficient | Beep once every second | 21 [△] |
| 22 | Parallel forbidden without battery | Beep once every second | 22 [△] |
| 25 | Parallel inverters' capacity different | Beep once every second | 25 [△] |
| 33 | BMS communication loss | Beep once every second | 33 [△] |
| 34 | Cell over voltage | Beep once every second | 34 [△] |

| Warning Code | Warning Event | Audible Alarm | Icon flashing |
|--------------|----------------------------|------------------------|-----------------|
| 35 | Cell under voltage | Beep once every second | 35 [△] |
| 36 | Total over voltage | Beep once every second | 36 [△] |
| 37 | Total under voltage | Beep once every second | 37 [△] |
| 38 | Discharge over voltage | Beep once every second | 38 [△] |
| 39 | Charge over voltage | Beep once every second | 39 [△] |
| 40 | Discharge over temperature | Beep once every second | 40 [△] |
| 41 | Charge over temperature | Beep once every second | 41 [△] |
| 42 | Mosfet over temperature | Beep once every second | 42 [△] |
| 43 | Battery over temperature | Beep once every second | 43 [△] |
| 44 | Battery under temperature | Beep once every second | 44 [△] |
| 45 | System shut down | Beep once every second | 45 [△] |

4.3 Specification

| Model | Sunova-eFox-WP-35E | Sunova-eFox-WP-50E |
|-----------------------------------|--|-----------------------|
| Battery | | |
| Rated voltage | 51.2V | |
| Voltage range | 44.8~57.6V | |
| Capacity | 10.24kWh | |
| Max. discharge rate | 0.7C | |
| Max. charge rate | 0.5C | |
| Battery type | Li-ion (LFP) | |
| AC Output(Backup) | | |
| Rated power | 3500W | 5000W |
| Surge power | 7000W,5s | 10000W,5s |
| Output voltage | 220/230/240Vac | 220/230/240Vac |
| Output current | 16A | 22.7A |
| Rated frequency | 50/60Hz | 50/60Hz |
| THDv | < 3% | < 3% |
| Output wave | Pure Sine Wave | Pure Sine Wave |
| Output type | AC Socket×2 | AC Socket×2 |
| AC Input | | |
| AC input voltage range | 170~280Vac | 170~280Vac |
| AC input frequency | 50/60Hz | 50/60Hz |
| AC charge current(Battery) | 30A(0~60A) Adjustable | 30A(0~80A) Adjustable |
| PV Input | | |
| Max. PV power(Recommended) | 4500W | 6000W |
| Max. PV voltage | 450V | 450V |
| MPPT voltage range | 120~430V | 120~430V |
| Max PV charge current(Battery) | 80A | 100A |
| General Data | | |
| Range of working temperature | Charge: 0°C~50°C/Discharge: -10°C~50°C | |
| Optimal working temperature range | 20°C~30°C | |
| Storage temperature | -15°C~60°C | |
| Humidity | 5%~95% | |
| Cooling strategy | Fan | |
| Weight | 120 kg | |
| Dimension [W x H x D] | 660*1150*200mm | |
| Package | wooden case | |
| Enclosure protection rating | IP44 | |
| Communication | WiFi/RS485 | |


4.4 Trouble Shooting

| Problem | LCD/LED/Buzzer | Explanation / Possible cause | What to do |
|---|---|---|--|
| Unit shuts down automatically during start up process. | LCD/LEDs and buzzer will be active for 3 seconds and then complete off. | The battery voltage is too low(<setting in program 5) | <ol style="list-style-type: none"> 1. Re-charge battery. 2. Replace battery. |
| No response after power on. | No indication. | <ol style="list-style-type: none"> 1. The battery voltage is far too low. 2. Battery polarity connect reversed. | <ol style="list-style-type: none"> 1. Check if batteries and the wiring are connected well. 2. Re-charge battery. 3. Replace battery. |
| Mains exist but the unit works in battery mode. | Input voltage displayed as 0 on the LCD and green LED is flashing. | Input protector is tripped | Check if AC breaker is tripped and AC wiring is connected well. |
| | Green LED is flashing. | Insufficient quality of AC power. (Shore or Generator) | <ol style="list-style-type: none"> 1. Check if AC wires are too thin and/or too long. 2. Check if generator (if applied) is working well or if input voltage setting is correct. (UPS appliance) |
| | Green LED is flashing. | Set "Solar First" as the priority of output source. | Change output source priority to Utility first. |
| When the unit is turned on, internal relay is switched on and off repeatedly. | LCD display and LEDs are flashing | Battery is disconnected. | Check if battery wires are connected well. |
| Buzzer beeps continuously and red LED is on. | Fault code 01 | Fan fault | Replace the fan. |
| | Fault code 05 | Output short circuited. | Check if wiring is connected well and remove abnormal load. |
| | Fault code 02 | Internal temperature of inverter component is over 100°C. | Check whether the air flow of the unit is blocked or whether the ambient temperature is too high. |
| | Fault code 03 | Battery is over-charged. | Return to repair center. |
| The battery voltage is too high. | | Check if spec and quantity of batteries are meet requirements. | |

| Problem | LCD/LED/Buzzer | Explanation/Possible cause | What to do |
|--|------------------------|---|---|
| Buzzer beeps continuously and red LED is on. | Fault code 06/58 | Output abnormal (Inverter voltage below than 190Vac or is higher than 260Vac) | 1. Reduce the connected load. 2. Return to repair center |
| | Fault code 07 | Overload error. The inverter is overload 110% and time is up. | Reduce the connected load by switching off some equipment. |
| | Fault code 08/09/53/57 | Internal components failed. | Return to repair center. |
| | Fault code 51 | Over current or surge. | Restart the unit, if the error happens again, please return to repair center. |
| | Fault code 52 | Bus voltage is too low. | |
| | Fault code 55 | Output voltage is unbalanced. | |
| | Fault code 56 | Battery is not connected well or fuse is burnt. | If the battery is connected well, please return to repair center. |

4.5 Activation

If you accidentally discharge the battery capacity to zero and can't turn it on, you need to activate it by connecting PV or Utility grid to reuse it.





Sunova Solar Technology Co., Ltd

Add: H building, Standard Plant Phase II,
Runzhou Road, Huishan District, Wuxi City,
Jiangsu Province, P.R.China, 214000

E-mail: info@sunova-solar.com

Tel: +86 510 8595 9369

Web: www.sunova-solar.com